

TP3000WC

DATA SHEET

ProWeatherStation™

Features

- No Assembly Required Easy setup
- 48 sec data update, instantaneous average and peak
- Inside and Outside Temperature and Humidity
- Solar Insolation and UV Index Measurement
- Wind Speed and Direction Including Average and Gust
- Wind Chill and Dew Point Temperature Display
- Barometric Pressure with last 12hr history, Weather Forecast
- Rain Gauge with Last Hour, Day, Week, Month or Total
- Built-in Data Logging for 4080 Readings: Unlimited with PC
- Settable Alarms and Resettable Min/Max History
- User Programmable Calibration Factors
- Up to 330 Ft (100m) Wireless Range Between Transmitter and Base Station
- Solar Powered Transmitter with 2 AA Batteries for backup.
- Free WeatherSmart WiFi Windows Software

RoHS

Applications

- Weather Tracking and Forecasting
- Solar Insolation Site Survey Measure how much sun power is available at a particular site
- Wind Turbine Site Survey Record wind speed at site over time to determine available true wind power
- Remote Temperature and Humidity Monitoring

Description

The ProWeatherStation™ is a high performance wireless data logging weather station with advanced sensor technology resulting in good accuracy at a low cost. It provides instantaneous and historical data on Inside and Outside Temperature and Humidity, Wind Speed (average and gust), Wind Direction, Solar Intensity and UV Index, Barometric Pressure and Rainfall. The backlit base station logs 4080 data points with adjustable sample interval. There is a memory meter on the display that shows when the memory is getting full so the data can be downloaded and archived to a computer thru WiFi and the included WeatherSmart WiFi software. The base station also allows automatic upload of data to Weather Underground and Weather Cloud via WiFi with no PC necessary.

The unit has an internet clock for improved accuracy. The Base Station runs on 3 AA Alkaline or Lithium batteries and can be mounted up to 100m (330 feet) away from the transmitter/sensor array. To use the WiFi feature, the Base Station must be powered with the included 5V power adapter. The transmitter/sensor array is solar powered and requires 2 AA batteries (included) for backup power.

The ProWeatherStation™ comes with an advanced solar powered sensor array (anemometer, wind direction meter, temp/humidity sensor, rain gauge, solar/light sensor), Ubolt brackets for mounting to a 1-1.6" pole, WiFi enabled wireless base station/display, 5V AC/DC adapter, and WeatherSmart WiFi Windows software. Note: 3 AA alkaline or Lithium batteries for the base station backup power are not included.






ProWeatherStation™

ProWeatherStation


Specifications

Display Ranges	
Wind Chood	0-112 MPH (0-50m/s)
Wind Speed	Accuracy: +/- 1m/s (<10 m/s) +/- 10% (>10 m/s) Displays in mph, m/s, km/h, knots or Beaufort
Outdoor Temperature	Displays in mph, m/s, km/h, knots or Beaufort -40 to 65°C (-40 to 149°F) 0.1 °C resolution
-	Displays in °C or °F Accuracy: +/-1°C 0 to 50°C (32 to 122°F) 0.1 °C resolution
Indoor Temperature	Displays in °C or °F Accuracy: +/-1°C
Humidity	30-80% Accuracy: +/-5% @25C
Rain Gauge	0-9999mm (394 inches) 0.1mm resolution (<1000mm) 1.0mm (>1000mm) Accuracy: +/- 10% Displays in mm or inches (hour,day,week,month or total)
Barometric Pressure	8.85 to 32.5 inHg 0.01inHg resolution Within range 27.13 to 31.89 inHg Accuracy: +/-3 hpa Displays in inHG or hPa
Wind Direction	LCD Compass 22.5° resolution
Light Measurement	0-300,000 lux
Wireless Transmitte	er / Sensor Array
Operating Frequency	433 MHz
Update Interval	48 secs
Operating Distance	Up to 100 meters (300 feet) between transmitter and base station
Wind Survivability	200 km/h (125 mph)
Construction	UV resistant white thermoplastic
Power Source	Solar Powered, AA Batteries (included) for backup
Mounting	Top of Pole (1-1.6" dia) mount using 2 stainless u-bolts
94.11.119	1
Base Station Specs	
Base Station Specs	Base Station or Computer (WiFi setup via smartphone app –
Base Station Specs	Base Station or Computer (WiFi setup via smartphone app – WSTOOLS)
Base Station Specs Setup Display	Base Station or Computer (WiFi setup via smartphone app – WSTOOLS) Backlit LCD, White Colored Frame
Base Station Specs Setup Display Memory Capacity	Base Station or Computer (WiFi setup via smartphone app – WSTOOLS) Backlit LCD, White Colored Frame 4080 data samples (memory meter on display)
Base Station Specs Setup Display Memory Capacity Computer Interface	Base Station or Computer (WiFi setup via smartphone app – WSTOOLS) Backlit LCD, White Colored Frame 4080 data samples (memory meter on display) WiFi
Base Station Specs Setup Display Memory Capacity Computer Interface Included Software	Base Station or Computer (WiFi setup via smartphone app – WSTOOLS) Backlit LCD, White Colored Frame 4080 data samples (memory meter on display) WiFi WeatherSmart WiFi Windows software 3 type AA LR6 Alkaline (not included) gives 1 year battery life. To extend battery life, Base Station can also be powered
Base Station Specs Setup Display Memory Capacity Computer Interface Included Software Batteries	Base Station or Computer (WiFi setup via smartphone app – WSTOOLS) Backlit LCD, White Colored Frame 4080 data samples (memory meter on display) WiFi WeatherSmart WiFi Windows software 3 type AA LR6 Alkaline (not included) gives 1 year battery life. To extend battery life, Base Station can also be powered via 5V AC adapter (included).
Base Station Specs Setup Display Memory Capacity Computer Interface Included Software Batteries Dimensions (L x W x H)	Base Station or Computer (WiFi setup via smartphone app – WSTOOLS) Backlit LCD, White Colored Frame 4080 data samples (memory meter on display) WiFi WeatherSmart WiFi Windows software 3 type AA LR6 Alkaline (not included) gives 1 year battery life. To extend battery life, Base Station can also be powered via 5V AC adapter (included). 177 x 152 x 50mm (7" x 6" x 2") Wall or desktop
Base Station Specs Setup Display Memory Capacity Computer Interface Included Software Batteries Dimensions (L x W x H) Mounting	Base Station or Computer (WiFi setup via smartphone app – WSTOOLS) Backlit LCD, White Colored Frame 4080 data samples (memory meter on display) WiFi WeatherSmart WiFi Windows software 3 type AA LR6 Alkaline (not included) gives 1 year battery life. To extend battery life, Base Station can also be powered via 5V AC adapter (included). 177 x 152 x 50mm (7" x 6" x 2")
Base Station Specs Setup Display Memory Capacity Computer Interface Included Software Batteries Dimensions (L x W x H) Mounting General Specs	Base Station or Computer (WiFi setup via smartphone app – WSTOOLS) Backlit LCD, White Colored Frame 4080 data samples (memory meter on display) WiFi WeatherSmart WiFi Windows software 3 type AA LR6 Alkaline (not included) gives 1 year battery life. To extend battery life, Base Station can also be powered via 5V AC adapter (included). 177 x 152 x 50mm (7" x 6" x 2") Wall or desktop Temp, Humidity, Wind Chill, DewPoint, Rainfall, Wind Speed,
Base Station Specs Setup Display Memory Capacity Computer Interface Included Software Batteries Dimensions (L x W x H) Mounting General Specs Settable Alarms	Base Station or Computer (WiFi setup via smartphone app – WSTOOLS) Backlit LCD, White Colored Frame 4080 data samples (memory meter on display) WiFi WeatherSmart WiFi Windows software 3 type AA LR6 Alkaline (not included) gives 1 year battery life. To extend battery life, Base Station can also be powered via 5V AC adapter (included). 177 x 152 x 50mm (7" x 6" x 2") Wall or desktop Temp, Humidity, Wind Chill, DewPoint, Rainfall, Wind Speed, Wind Gust, Barometric Pressure, Light, UV Index, Heat Index
Base Station Specs Setup Display Memory Capacity Computer Interface Included Software Batteries Dimensions (L x W x H) Mounting General Specs Settable Alarms Alarm duration	Base Station or Computer (WiFi setup via smartphone app – WSTOOLS) Backlit LCD, White Colored Frame 4080 data samples (memory meter on display) WiFi WeatherSmart WiFi Windows software 3 type AA LR6 Alkaline (not included) gives 1 year battery life. To extend battery life, Base Station can also be powered via 5V AC adapter (included). 177 x 152 x 50mm (7" x 6" x 2") Wall or desktop Temp, Humidity, Wind Chill, DewPoint, Rainfall, Wind Speed, Wind Gust, Barometric Pressure, Light, UV Index, Heat Index Up to 120 seconds
Base Station Specs Setup Display Memory Capacity Computer Interface Included Software Batteries Dimensions (L x W x H) Mounting General Specs Settable Alarms Alarm duration Time Setting	Base Station or Computer (WiFi setup via smartphone app – WSTOOLS) Backlit LCD, White Colored Frame 4080 data samples (memory meter on display) WiFi WeatherSmart WiFi Windows software 3 type AA LR6 Alkaline (not included) gives 1 year battery life. To extend battery life, Base Station can also be powered via 5V AC adapter (included). 177 x 152 x 50mm (7" x 6" x 2") Wall or desktop Temp, Humidity, Wind Chill, DewPoint, Rainfall, Wind Speed, Wind Gust, Barometric Pressure, Light, UV Index, Heat Index Up to 120 seconds Automatic thru Internet, Perpetual Calendar
Base Station Specs Setup Display Memory Capacity Computer Interface Included Software Batteries Dimensions (L x W x H) Mounting General Specs Settable Alarms Alarm duration Time Setting Time Display	Base Station or Computer (WiFi setup via smartphone app – WSTOOLS) Backlit LCD, White Colored Frame 4080 data samples (memory meter on display) WiFi WeatherSmart WiFi Windows software 3 type AA LR6 Alkaline (not included) gives 1 year battery life. To extend battery life, Base Station can also be powered via 5V AC adapter (included). 177 x 152 x 50mm (7" x 6" x 2") Wall or desktop Temp, Humidity, Wind Chill, DewPoint, Rainfall, Wind Speed, Wind Gust, Barometric Pressure, Light, UV Index, Heat Index Up to 120 seconds Automatic thru Internet, Perpetual Calendar 12hr or 24hr

WeatherSmart WiFi Software



Main WeatherSmart Screen



Stored Data in Text Format - can export to Excel



Stored Data in Graph Format

For further information contact: Tyc